


Telegesis		TG-ETRX-R212-AT-Commands	1
ETRX1 and ETRX2		AT-Command Dictionary	2.12

**TG-ETRX-R212-AT-Commands**  
**ETRX1 AND ETRX2 WIRELESS MESH**  
**NETWORKING MODULES**  
**AT-Command Dictionary**



**Current Firmware R212**

**Telegesis**

Telegesis		TG-ETRX-R212-AT-Commands	2
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## Table of Contents

1	INTRODUCTION.....	3
1.1	Document Overview.....	3
1.2	A Note on ZigBee® Compliance (updated).....	4
1.3	Important notes .....	4
2	AT STYLE COMMAND CONVENTIONS .....	5
2.1	Parameters.....	6
2.2	Prompt Overview.....	7
2.3	Device Overview.....	8
2.4	AT Command Overview.....	9
2.4.1	Module Control & Configuration Commands.....	10
2.4.2	Network Control & Configuration Commands .....	15
3	LIST OF ERROR CODES.....	31
4	S-REGISTERS.....	32
4.1	Recovery of the Factory Default Settings.....	33
4.2	S-Registers for Radio Setup .....	34
4.3	S-Registers for Module Setup.....	36
4.4	I/O related S-Registers.....	41
4.5	S-Registers Defining the Functionality of the Module.....	46
4.6	Device Specific S-Registers.....	55
5	BUILT IN FUNCTIONALITY .....	58
6	POWER CONSUMPTION.....	61
6.1	ETRX1 Power Consumption.....	61
6.2	ETRX2 Power Consumption.....	62
7	NOTES ON BACKWARDS COMPATIBILITY WITH ETRX1 .....	63
8	NOTES ON ENERGY LEVELS AND LQI .....	64
8.1	Interpreting LQI on the ETRX2.....	64
8.2	Interpreting LQI on the ETRX1 .....	65
8.3	Interpreting RSSI Energy Levels on the ETRX1 .....	66
8.4	Interpreting RSSI Energy Levels on the ETRX2 .....	66
9	TRADEMARKS.....	67
10	DISCLAIMER.....	67
11	CONTACT INFORMATION .....	67
12	REFERENCES.....	67

Telegesis		TG-ETRX-R212-AT-Commands	3
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 1 Introduction

This document describes the AT-Command interface of the ETRX1 and ETRX2, IEEE 802.15.4 wireless meshing modules.

The Telegesis ETRX1 and ETRX2 modules have been designed to be built into any device and provide a low cost, low power IEEE802.15.4 wireless mesh networking solution based on the EmberZNet2.xx meshing stack. Integration into a wide range of applications is made easy using a simple AT-style software interface and advanced hardware design.

No RF experience or expertise is required to add this powerful wireless networking capability to your products. The ETRX1 and ETRX2 offer fast integration opportunities and the shortest possible time to market for your product.

### 1.1 Document Overview

This document is meant as an AT-Command and S-Register reference for R2xx revisions of the firmware based on EmberZNet2.x. In order to learn how your products can profit from wireless mesh networking please also refer to the following documents:

- ETRX1 or ETRX2 Product Manual
- ETRX1 or ETRX2 Development Kit User Guide
- ETRX1 or ETRX2 R2xx Firmware User Guide

The ETRXn Product Manuals concentrate on the hardware specification of the respective modules. The Development Kit User Guide contains all of the information required to set up your development kit and run firmware upgrades where necessary. The Firmware User Guide gives you an overview of how to use the ETRXn wireless meshing modules.

For a command overview of the R1xx series of firmware based on EmberNet3.x please refer to the R1xx AT-Command Dictionary and Application Notes. Please note that R1xx series firmware and R2xx series firmware are not over-the-air compatible.

Telegesis		TG-ETRX-R212-AT-Commands	4
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 1.2 A Note on ZigBee® Compliance (updated)

The firmware revisions R2xx are based on the EmberZNet2.x mesh stack, which overcomes many of the limitations of the ZigBee® 2006 Home Controls profile, which is the only profile ratified by the ZigBee® Alliance at this time. As a result, an end product containing an ETRX1 or ETRX2 based on firmware revisions R2xx cannot yet be certified to be tested for ZigBee® compliance.

EmberNet 2.x already contains many of the features that are expected to find its way into the upcoming release of the ZigBee® specification.

If you require your product to be tested for ZigBee® compliance, you can talk to us about supplying a custom version of our firmware tailored for this requirement, once you have become a member of the ZigBee® Alliance, which is a prerequisite for offering products with ZigBee® certification.

The ETRX1 and ETRX2 run a private application profile, as the functionality of the module cannot be pressed into any of the existing application profiles (like lighting). The profile ID used is 0xC090. This also means that interoperation with 3<sup>rd</sup> party ZigBee® nodes is unlikely.

Both Ember, as a promoting member, and Telegesis, as a participating member of the ZigBee® Alliance, are working to evolve the firmware with the ZigBee® standard and any future stack and application profiles to offer our customers the best wireless mesh networking solution.

With the capability of in-field upgrading of firmware over the air, you will be able to react quickly and easily to changes in both the ZigBee® standard as well as your own requirements.

## 1.3 Important notes

The new Ember Bootloader which runs on the ETRX2 can be triggered using the command AT+BLOAD as described in Section 2, but it can also be triggered in hardware. If the A/D2 pin is pulled low during the boot-up of the module, the module will also enter the bootloader, so exercise caution when doing hardware design and ensure that this pin is not grounded during start-up and reset. If unused the pad can be left floating and a pull-up is not required.

**Important Note for the ETRX1:** From Revision R1005 of the Ember bootloader it is possible to enter the bootloader by pulling I/O5 low after a reset or during bootup. Make sure that I/O5 does not get pulled low externally to prevent entering the bootloader unintentionally!

Telegesis		TG-ETRX-R212-AT-Commands	5
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2 AT Style Command Conventions

To simplify the communication with the ETRXn modules, an AT-style command set, similar to the industry standard Hayes modem control language, is used.

Each command must be preceded by the "AT" or "at" prefix. To terminate a command enter <CR>. Any data not following this pattern is either not accepted by the module or will cause an error message in response.

Commands are followed by an optional response that includes <CR><LF><Response> and a prompt <CR><LF><Prompt><CR><LF> where the prompt could also be an error message.

Example:

```
ATS00?<CR>
<CR><LF>S00:FFFF
<CR><LF>OK<CR><LF>
```

It is recommended to wait for an "OK" or "ERROR:xx" prompt before issuing the next command.

Any data which is prompted to the user is delivered in the format <CR><LF><prompt><CR><LF>. Unless disabled in S07 or S08 prompts may appear whenever the corresponding event occurs.

Example:

```
<CR><LF><BCAST:000D6F000005A666=test><CR><LF>
```

A prompt intersecting a command being entered will not affect the command itself.

Throughout this document, only the responses and prompts are presented, <CR><LF> are omitted intentionally. Sequences of AT commands in a single line are not supported.

The ETRXn features a 128-byte FIFO to buffer incoming characters which is sufficient to hold even the longest possible command. To prevent a buffer overflow in channel mode XON/XOFF handshaking is used. Optional hardware handshaking can be enabled as described in the register description of S0B in section 4.

Read Command <b>ATXXX?</b>	Commands ending with a '?' return the currently set value of the parameter or parameters
Write Command <b>ATXXX=&lt;...&gt;</b>	This command sets user-definable parameters as indicated by the '=' sign.
Execution Command <b>ATXXX</b>	This command executes routines of the module and returns parameters

**Table 1: Types of AT commands**

Telegesis		TG-ETRX-R212-AT-Commands	6
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2.1 Parameters

Usually there are no optional parameter sets, so each parameter must be entered in the correct format.

<b>XX</b>	8-bit hexadecimal number. Valid characters are 0-9, a-f and A-F
<b>n</b>	Number from 0-9
<b>s</b>	Sign
<b>b</b>	Bit (0 or 1)
<b>c</b>	character
<b>PPPP</b>	16-bit hexadecimal PAN ID (0x0000 to 0x3FFF)
<b>CC</b>	decimal channel (802.15.4 channel 11-26)
<b>&lt;EUI64&gt;</b>	64-bit IEEE802.15.4 address in hexadecimal

**Table 2:** Different formats of parameters

Telegesis		TG-ETRX-R212-AT-Commands	7
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2.2 Prompt Overview

The following prompts can show up during the operation of the ETRX1 and ETRX2 modules. Most of the prompts can be disabled using register S07 and S08.

Prompt Overview	
<b>JPAN: CC,PPPP</b>	The Node has joined a PAN on channel CC with PAN ID PPPP
<b>LeftPAN</b>	The node has left the PAN
<b>UCAST:&lt;EUI64&gt;=&lt;data&gt;[,&lt;length&gt;]</b>	Reception of a Unicast
<b>BCAST:&lt;EUI64&gt;=&lt;data&gt;[,&lt;length&gt;]</b>	Reception of a Broadcast
<b>RAW:&lt;data&gt;</b>	Reception of raw data
<b>SCAST:&lt;EUI64&gt;=&lt;data&gt;[,&lt;length&gt;]</b>	Reception of a Scast (Data sent to the sink)
<b>ACK:nn</b>	Receipt for successful acknowledgement of a message
<b>NACK:nn</b>	Notification of missing acknowledgement
<b>CHAN:&lt;EUI64&gt;</b>	A request to open a channel
<b>OPEN</b>	A channel has been opened
<b>CLOSE</b>	A channel has been closed
<b>NEUNODE:&lt;EUI64&gt;</b>	A new node has joined the network
<b>SINK:&lt;EUI64&gt;</b>	A new sink was found and stored
<b>[REM]SED:&lt;EUI64&gt;</b>	A sleepy end device has been found
<b>[REM]MED:&lt;EUI64&gt;</b>	A mobile sleepy end device has been found
<b>[REM]FFD:&lt;EUI64&gt;</b>	A router has been found
<b>[REM]COO:&lt;EUI64&gt;</b>	A coordinator has been found
<b>COUNT:&lt;EUI64&gt;,XX,&lt;ioread&gt;,&lt;A/D1&gt;,&lt;A/D2&gt;</b>	Triggered by action 2000 (see section 5)
<b>NDAATA:&lt;EUI4&gt;,XX,&lt;ioread&gt;,&lt;A/D1&gt;,&lt;A/D2&gt;</b>	Triggered by actions 0110 - 0113 (see section 5)
<b>SDAATA:&lt;EUI64&gt;,&lt;ioread&gt;,&lt;A/D1&gt;,&lt;A/D2&gt;</b>	Triggered by actions 0100 - 0103 (see section 5)
<b>&lt;plaintext&gt;</b>	Message prompted on the sink (see section 5, functionality 0108 – 010B)
<b>Snn[x]:&lt;data&gt;:&lt;EUI64&gt;</b>	Remote S-Register reading
<b>NAK:&lt;EUI64&gt;</b>	A request to a remote node with EUI64 was not acknowledged.
<b>PWRCHANGE:nn</b>	Indicates a change of power mode caused by an action

**Table 3:** Prompt Overview

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	8
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2.3 Device Overview

Table 4 gives an overview of the device types mentioned in this document and elsewhere.

Device Types		Also known as
<b>COO</b>	Coordinator	ZigBee Coordinator (ZC)
<b>FFD</b>	Router	ZigBee Router
<b>SED</b>	Sleepy End Device	ZigBee End Device (ZED)
<b>MED</b>	Mobile Sleepy end Device	

**Table 4:** Device Overview

The terms Full Function device (FFD) and Reduced Function Device (RFD) are obsolete, but the abbreviations are retained in the R212X firmware to avoid problems with users' legacy application software.

Telegesis		TG-ETRX-R212-AT-Commands	9
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2.4 AT Command Overview

The following table gives a quick reference of all commands available.

Command Overview	
ATI	Display product identification information
ATZ	Software reset
AT&F	Restore factory settings
AT+BLOAD	Enter the bootloader menu
AT+CLONE	Clone the local node's firmware to a remote node
AT+RECOVER	Recover from a failed clone attempt (ETRX2 only)
AT+PASSTHROUGH	Enter pass-through bootloading mode (ETRX1 only)
ATS	S-Register access
ATSALL	Write all remote S-Registers
AT+TOKDUMP	Display all local S-registers
ATSREM	Remote S-register access
AT+ESCAN	Scan the energy of all channels
AT+EN	Establish PAN
AT+JN	Join next best network
AT+PANSCAN	Scan for active PANs
AT+JPAN	Join specific PAN
AT+DASSL	Disassociate local device from PAN
AT+DASSR	Disassociate remote device from PAN
AT+NTABLE	Show the neighbour table
AT+N	Display network parameters
AT+CTABLE	Display list of local children
AT+PARENT	Display Parent's ID
AT+POLL	Poll Parent for data
AT+SN	Scan network for other nodes
AT+REMSN	Scan for remote device's direct neighbours
AT+LINKCHECK	Check link parameters with a neighbour
AT+PING	Indicate presence in the network
AT+BCAST	Transmit a broadcast
AT+BCASTB	Transmit a broadcast of binary data
AT+UCAST	Transmit a unicast
AT+UCASTB	Transmit a unicast of binary data
AT+SCAST	Transmit data to the Sink
AT+SCASTB	Transmit binary data to the sink
AT+SSINK	Search for a sink
AT+SINK	Display the local Node's sink
AT+OPCHAN	Opens a channel to a remote node
+++	Close channel
AT+OPLCHAN	Opens a limited channel to a remote node
AT+ACKCHAN	Accept channel
AT+RDATAB	Send binary raw data
AT+IDENT	Play a tune on remote devboard

**Table 5:** Command Overview

Telegesis		TG-ETRX-R212-AT-Commands	10
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2.4.1 Module Control & Configuration Commands

### I – Display Product Identification Information

Execute Command <b>ATI</b>	Response <b>Telegesis ZigBee</b> <b>Rnnn[X A]</b> <b>&lt;EUI64&gt;</b> <b>OK</b>
	Where nnn is the firmware revision and <EUI64> is the Device's IEEE 802.15.4 identifier In addition to announcing itself as either an ETRX1 or ETRX2 the firmware revision is also clearly marked to be for either the AVR platform of the ETRX1 (A prefix), or the XAP16B platform of the ETRX2 (X prefix).
SW release	R208 - added ETRX1 and ETRX2 differentiator

### Z – Software Reset

Execute Command <b>ATZ</b>	Response Module Performs a software reset All non-volatile S Registers keep the user defined values, if the module was part of a PAN it will remain part of it.
SW release	R200

### &F – Restore Factory Defaults

Execute Command <b>AT&amp;F</b>	Response Module Performs a factory reset All non-volatile S Registers are updated with their factory defaults. In order to leave the network as well use the AT+DASSL command after executing AT&F
SW release	Modified in R206

### +BLOAD – Enter The Bootloader Menu

Execute Command <b>AT+BLOAD</b>	Response <b>&lt;entering bootloader&gt;</b>
	The device leaves the AT command line and enters the Ember bootloader menu for downloading new firmware. A description of the bootloading process can be found in the devkit manuals. Please note that the bootloader menu will run at a data rate of 38k4 (ETRX1) or 115k2 (ETRX2), no parity, 8 data bits regardless of the current data rate and the SOB register setting.
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	11
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +PASSTHROUGH – Bootload Remote Node In Passthrough Mode (ETRX1 only)

Execute Command <b>AT+PASSTHROUGH:&lt;EUI64&gt;,cccccccc</b>	Response <b>Press Enter for BL menu...</b> or <b>ERROR&lt;errorcode&gt;</b>
Note This command is available on the ETRX1 only. <b>The default password on both ETRX1 and ETRX2 is “TG-ETRX1”.</b>	Where <errorcode> represents the error code explained in section 3. Allows you to bootload a remote node which address is given by <EUI64> as described in the ETRX1 Devkit manual. cccccccc represents the remote nodes 8 character password. After completion a soft reset is performed on the remote end.
SW release	R200

### +CLONE – Clone Local Node To Remote Node

Execute Command <b>AT+CLONE:&lt;EUI64&gt;,cccccccc</b>	Response <b>Cloning...</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on: All devices	
Note On the ETRX1 cloning is only supported if the local Ember bootloader has revision >1005. Error 30 will be displayed if this is not the case. On the ETRX1 the local node will reset after successful bootloading, on the ETRX2 the node will continue operation without a reset. <b>The default password on both the ETRX1 and ETRX2 is “TG-ETRX1”.</b>	Where <errorcode> represents the error code explained in section 3. Clones the firmware of the local node to a remote node which address is given by <EUI64>. cccccccc represents the remote nodes 8 digit password. After completion a soft reset is caused on the remote end.
SW release	R208 added to the ETRX2

### +RECOVER – Recover From A Failed Clone Attempt (ETRX2 only)

Execute Command <b>AT+RECOVER</b>	Response <b>Recovering...</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on: All devices	
Note Use this command in cases where the cloning operation was interrupted and the remote device therefore remains in the bootloader. For more information on over-the-air firmware upgrading please refer to the respective Development Kit Manual.	Where <errorcode> represents the error code explained in section 3. Clones the firmware of the local node to a remote node which is already in the bootloader.
SW release	R208

Telegesis		TG-ETRX-R212-AT-Commands	12
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S – S-Register Access

<p>Read Command <b>ATSnn[x]?</b></p>	<p>Response <b>Snn:&lt;data&gt;</b> <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b></p> <p>The module displays the contents of S-register nn or an error message, where &lt;errorcode&gt; represents the error code explained in section 3. All 16-bit registers can also be accessed bit by bit. In order to do this [x] may specify the bit which is to be read. The result when reading a single bit will always be 0 or 1.</p>
<p>Write Command <b>ATSnn[x]=&lt;data&gt;</b></p> <p>Note Some S-Registers require a password for write access. See S-Register description for details. <b>The default password on both ETRX1 and ETRX2 is “TG-ETRX1”.</b> Some S-Registers are read-only and will return an error if you are trying to write to them</p>	<p>Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b></p> <p>The data is written to S-register number nn and if applicable stored in non-volatile EEPROM. The data format for each individual S Register is given in the S-Register description. &lt;errorcode&gt; represents the error code explained in section 3. For all 16-bit registers individual bits can also be set or cleared by specifying the bit using [x] and setting it to either 0 or 1.</p>
SW release	R200

### SALLnn – Write All Remote S-Registers

<p>Write Command <b>ATSALLnn[x]=&lt;data&gt;</b></p> <p>Use on: All Devices</p> <p>Note Use this command carefully to prevent setting registers of units you do not want to alter. Also be aware that there are no guarantees that each and every node in the network is reached.</p>	<p>Response <b>OK</b></p> <p>Or <b>ERROR&lt;errorcode&gt;</b></p> <p>The module broadcasts a write command to all remote nodes on the PAN. Every remote module receiving this request will perform the command. nn specifies the register number which is written. For all 16-bit registers individual bits can also be set or cleared by specifying the bit using [x] and setting it to either 0 or 1.</p>
SW release	R208 – Individual bits can now be set

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	13
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### SREMn – Remote S-Register Access

<p>Read Command <b>ATSREMnn[x]:&lt;EUI64&gt;?</b></p> <p>Use on: All Devices</p>	<p>Response <b>Snn:&lt;data&gt;</b> <b>OK</b></p> <p>or</p> <p><b>ERROR&lt;errorcode&gt;</b></p> <p>The module displays the contents of S-Register nn or an error message, where &lt;errorcode&gt; represents the error code explained in section 3. The data format of each individual S-Register is given in the S-Register description. All 16-bit registers can also be accessed bit by bit. In order to do this [x] may specify the bit which is to be read. The result when reading a single bit will always be 0 or 1.</p> <p>In case bit 14 of S06 is set the response will be</p> <p><b>OK</b></p> <p>In this case the OK prompt only shows successful transmission of the read request. The actual reading of the S-Register will be prompted later in the following format:</p> <p><b>Snn:&lt;Data&gt;:&lt;EUI64&gt;</b></p> <p>This allows up to 10 requests to 4 different nodes to be in flight at any one time. In case the target node could not be reached the following prompt will be displayed:</p> <p><b>NAK:&lt;EUI64&gt;</b></p>
<p>Write Command <b>ATSREMnn[x]:&lt;EUI64&gt;=&lt;data&gt;</b></p> <p>Note Some S-Registers are read only and will return an error if you are trying to write to them Some S-Registers require a password for write access. See S-Register description for details. <b>The default password on both ETRX1 and ETRX2 is “TG-ETRX1”.</b></p>	<p>&lt;data&gt; is written to remote S-register number nn and if applicable stored in non-volatile memory.</p> <p>Response <b>OK</b></p> <p>Or if any problems occur</p> <p><b>ERROR&lt;errorcode&gt;</b></p> <p>Where &lt;errorcode&gt; represents the error code explained in section 3. For all 16-bit registers individual bits can also be set or cleared by specifying the bit using [x] and setting it to either 0 or 1.</p>
<p>SW release</p>	<p>R200</p>

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	14
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### **TOKDUMP – Display All S-Registers**

Execute Command <b>AT+TOKDUMP</b>	<p>Response</p> <p><b>+TOKDUMP:</b></p> <p><b>&lt;data&gt;</b></p> <p><b>OK</b></p> <p>Or</p> <p><b>ERROR&lt;errorcode&gt;</b></p> <p>The module displays the contents of all local S-registers or an error message, where &lt;errorcode&gt; represents the error code explained in section 3. The data format for each individual S Register is given in the S-Register description in section 4.</p>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	15
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 2.4.2 Network Control & Configuration Commands

<b>+ESCAN – Scan The Energy Of All Channels</b>	
Execute Command <b>AT+ESCAN</b>	Response <b>+ESCAN:</b> <b>11:XX</b> <b>12:XX</b> ... <b>26:XX</b> <b>OK</b>
Use on: All nodes which are not part of a PAN	or <b>ERROR&lt;errorcode&gt;</b>
Note Scanning all channels can take up to 16 seconds. This command can only be executed if the local node is not part of a PAN. Use <b>AT+DASSL</b> to leave a PAN before executing this command.	<errorcode> represents the error code explained in section 3. XX represents the average energy on the respective channel (see description in Section 8). Channels masked out in S00 are not scanned.
SW release	R200

<b>+EN – Establish PANetwork</b>	
Execute Command <b>AT+EN</b>	Response <b>JPAN:CC,PPPP</b> <b>OK</b>
Use on: All nodes which are not part of a PAN	or <b>ERROR&lt;errorcode&gt;</b>
Note When issuing this command the local device becomes a Coordinator. Establishing a PAN can take up to 16 seconds. This command can only be executed if the local node is not part of a PAN already.	<errorcode> represents the error code explained in section 3.  The local node becomes a coordinator and performs an energy scan on all channels selected in S00. It then starts a PAN with a random unused PAN ID (PPPP) on the quietest channel (CC). It is possible to force the coordinator to a specific PAN ID and channel by selecting a single channel in S00 and setting S01 to a PAN ID other than FFFF. By default S00 and S01 are set to both FFFF, which causes the coordinator to pick a channel and PAN ID as described above. If S01 is not set to FFFF the content of S01 is used instead of a random PAN ID, given that the preferred PAN ID is not used by a different PAN. In case the PAN ID specified in S01 is already in use a randomly generated PAN ID will be used. The new network's encryption key is defined in S03. If S03 is set to all 0's (default) a random key will be generated.
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	16
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +JN – Join Network

<p>Execute Command <b>AT+JN</b></p> <p>Use on: All nodes which are not part of a PAN</p> <p>Note Joining a PAN can take up to 8 seconds, depending on the number of channels which need scanning. This command can only be executed if the local node is not part of a PAN already.</p>	<p>Response <b>JPAN:CC,PPPP OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3. The local node scans all channels selected in register S00 for the existence of a PAN. When finding a PAN which allows joining it will automatically join in via the remote node with the highest RSSI. In case register S01 differs from the default value of 0xFFFF the node will only join a PAN with the PAN ID specified in S01.</p>
<p>Remote Action Depending on settings in S06 the new node will be announced either at the coordinator or parent device. (See the User Guide for a more detailed description of network establishment)</p>	<p>Prompt <b>NEWNODE:&lt;EUI64&gt;</b></p>
SW release	R200

### +PANSCAN – Scan For Active PANs

<p>Execute Command <b>AT+PANSCAN</b></p> <p>Use on: All nodes which are not part of a PAN</p> <p>Note Scanning for active PANs can take up to 8 seconds. This command can only be executed if the local node is not part of a PAN already.</p>	<p>Response <b>+PANSCAN:CC,PPPP,b OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3. The node gives a list of all available PANs found. CC represents the channel, PPPP the PAN ID and b indicates whether the network is allowing additional nodes to join (0=joining not permitted, 1=joining allowed). The node does not join any of the PANs found.</p>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	17
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +JPAN – Join Specific PAN

Execute Command <b>AT+JPAN:CC,PPPP</b>	Response <b>JPAN:CC,PPPP</b> <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Where CC is the channel and PPPP is the PAN ID of the network which is to be joined.	<errorcode> represents the error code explained in section 3. The local node joins a particular PAN on channel CC with PAN ID PPPP via the remote node with the highest RSSI.
Use on All nodes which are not part of a PAN	
Note This command can only be executed if the local node is not part of a PAN already. The JPAN command is not affected by the channel mask in register S00.	
SW release	R200

### +DASSL – Disassociate Local Device From PAN

Execute Command <b>AT+DASSL</b>	Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on All Devices which are part of a PAN	Prompt <b>LeftPAN</b>  <errorcode> represents the error code explained in section 3. Instruct local device to leave the PAN.
SW release	R200

### +DASSR – Disassociate Remote Device From PAN

Execute Command <b>AT+DASSR:&lt;EUI64&gt;</b>	Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on All Devices which are part of a PAN	<errorcode> represents the error code explained in section 3. Instruct remote device to leave the PAN.
Remote action	Prompt <b>LeftPAN</b>
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	18
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +NTABLE – Display the Neighbour Table

<p>Read Command <b>AT+NTABLE?</b></p> <p>Displays the local device's neighbour table. The neighbour table contains devices within a single hop of the local node.</p> <p>Use on All Devices</p> <p>SW release</p>	<p>Response</p> <p>ShortID   LQI   inCost   outCost   age   EUI ...</p> <p><b>OK</b></p> <p>The short ID is the 16-bit network ID of the neighbouring device, inCost and outCost are an indicator of the link quality between the local node and the remote node, age is the number of intervals during which the local node has not heard from that particular neighbour (in 16 second increments) and EUI is the neighbour's EUI64.</p> <p>R200</p>
---	---

### +N – Display Network Information

<p>Read Command <b>AT+N?</b></p> <p>Use on All Devices</p> <p>SW release</p>	<p>Response</p> <p><b>+N:XXX,CC,PPPP,sZZ</b></p> <p>or <b>NoPAN</b></p> <p>followed by <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3. XXX represents the nodes functionality in the PAN (FFD,COO,SED,MED), YY represents the IEEE802.15.4 radio channel (11-26), PPPP represents the node's PAN ID and ZZ represents the radio output power in dBm.</p> <p>R200</p>
--	---

### +POLL – Poll The Parent Device

<p>Execute Command <b>AT+POLL</b></p> <p>Poll the parent device for new data.</p> <p>Note: Action 0011 is recommended for periodic polling.</p> <p>Use on SEDs MEDs</p> <p>SW release</p>	<p>Response</p> <p><b>OK</b></p> <p>or</p> <p><b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3.</p> <p>R207</p>
---	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	19
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +PARENT – Display Parent's ID

<p>Read Command <b>AT+PARENT?</b></p> <p>Display the Device's Parent EUI64.</p> <p>Use on SEDs MEDs</p>	<p>Response <b>+PARENT:&lt;EUI64&gt;</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3.</p>
SW release	R207

### +CTABLE – Display List Of Local Children

<p>Read Command <b>AT+CTABLE?</b></p> <p>Display the Device's children's EUI64 and the type (MED or SED).</p> <p>Use on Routers Coordinator</p>	<p>Response <b>+CTABLE</b> <b>index eui type</b> <b>&lt;list of children&gt;</b> <b>OK</b></p> <p>or <b>noChilds</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3.</p>
SW release	R207

### +SN – Scan Network

<p>Execute Command <b>AT+SN[:nn]</b></p> <p>Use on All Devices</p> <p>Note In case no parameter is specified 07 is used by default.</p>	<p>Response <b>OK or ERROR&lt;errorcode&gt;</b></p> <p>Prompt <b>FFD:&lt;EUI64&gt;[,syy,zz]</b> <b>SED:&lt;EUI64&gt;[,syy,zz]</b> <b>MED:&lt;EUI64&gt;[,syy,zz]</b> <b>COO:&lt;EUI64&gt;[,syy,zz]</b></p> <p>Parameters <b>nn ranging from 00 to 07</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3. In case bit 6 of register S06 is set the RSSI level (syy in dBm) and LQI (zz in hexadecimal) of the last hop are displayed. For a description of the LQI reading please see section 8. Only neighbours which are up to nn hops away are listed. If nn = 01 only direct neighbours will reply and nn = 00 will search the entire network.</p>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	20
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +REMSN – Scan For Remote Devices Direct Neighbours

Execute Command <b>AT+REMSN:&lt;EUI64&gt;</b>	Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on All Devices	Prompt <b>REMFFD:&lt;EUI64&gt;[,syy,zz]</b> <b>REMZED:&lt;EUI64&gt;[,syy,zz]</b> <b>REMSED:&lt;EUI64&gt;[,syy,zz]</b> <b>REMMED:&lt;EUI64&gt;[,syy,zz]</b> <b>REMC00:&lt;EUI64&gt;[,syy,zz]</b>
Note If the target device of this command is an end device the results will reflect its parent, therefore it is recommended to target this command at routers only.	<errorcode> represents the error code explained in section 3. In case bit 6 of register S06 is set the RSSI level (syy in dBm) and the LQI (zz in hexadecimal) read at the remote device are displayed. For a description of the LQI reading please see section 8. After execution of this command all direct neighbours of the node with id <EUI64> will report within 8 seconds.
SW release	R200

### +LINKCHECK – Check Link Parameters For Link With Neighbouring Device

Execute Command <b>AT+LINKCHECK:&lt;EUI64&gt;</b>	Response <b>+LINKCHECK=syy,zz</b> <b>OK</b>
Use on All Devices	or <b>ERROR&lt;errorcode&gt;</b>
	<errorcode> represents the error code explained in section 3.  The command will only be successful if the node with the identifier <EUI64> is a direct neighbour, parent or child of the local node. The RSSI level (syy in dBm) and LQI (zz in hexadecimal) of the last hop are displayed. For a description of the LQI reading please see section 8.
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	21
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +PING – Indicate Presence In The Network

Execute Command <b>AT+PING</b>	Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on All Devices	<errorcode> represents the error code explained in section 3.
Remote Action	Prompt <b>FFD:&lt;EUI64&gt;[,syy,zz]</b> <b>SED:&lt;EUI64&gt;[,syy,zz]</b> <b>MED:&lt;EUI64&gt;[,syy,zz]</b> <b>COO:&lt;EUI64&gt;[,syy,zz]</b>  The prompt above will be displayed on all nodes which can hear the ping. In case bit 6 of register S06 is set the RSSI level (syy dBm) and LQI (zz in hexadecimal) of the last hop are displayed. For a description of the LQI reading please see section 8.  <EUI64> is the identifier of the sending device
SW release	R200

### +BCAST – Transmit A Broadcast

Execute Command <b>AT+BCAST:nn,&lt;data&gt;</b>	Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on: All devices	Where <errorcode> represents the error code explained in section 3.  Parameters <b>nn ranging from 00 to 10</b>  Up to 65 bytes are sent. The response OK shows successful transmission. Successful transmission does not guarantee successful reception. To make sure data has been received by a specific node use a unicast message. Only neighbours which are up to nn hops away will receive the broadcast. If nn = 01 only direct neighbours will receive the broadcast and if n = 00 the entire network will.
Remote action	Prompt <b>BCAST:&lt;EUI64&gt;=&lt;data&gt;</b>  Every node in the PAN which has received the broadcast message will prompt the above message where <EUI64> is the address of the sender and <data> is the data which was attached to the broadcast
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	22
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +BCASTB – Transmit A Broadcast Of Binary Data

<p>Execute Command <b>AT+BCASTB:xx,nn</b></p> <p>Where xx is the number (in hexadecimal) of data bytes to be sent and nn is the number of hops the message will travel.</p> <p>Use on All Devices</p> <p>Note: This command is particularly useful if the data may contain &lt;CR&gt; and &lt;Backspace&gt; characters.</p>	<p>Response <b>&gt; &lt;data being entered&gt;</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>After the ‘&gt;’ prompt a number of xx characters are expected to be entered. &lt;errorcode&gt; represents the error code explained in section 3. In case bit D of S08 is set a timeout error is generated if no character is received for 1 second.</p> <p>Parameters <b>xx ranging from 00 to 41 (hex)</b> <b>nn ranging from 00 to 10</b></p> <p>Up to 65 bytes are sent to devices up to nn hops away. The response OK shows successful transmission. Successful transmission does not guarantee successful reception. To make sure data has been received by a specific node use a unicast message. Only neighbours which are up to nn hops away will receive the broadcast. If nn=01 only direct neighbours will receive the broadcast and if n = 00 the entire network will.</p>
<p>Remote action</p>	<p>Prompt <b>BCAST:&lt;EUI64&gt;,xx=&lt;data&gt;</b></p> <p>Every node in the PAN which has received the broadcast message will prompt the above message where &lt;EUI64&gt; is the address of the sender and xx is the length of the message in hexadecimal.</p>
<p>SW release</p>	<p>R200</p>

Telegesis		TG-ETRX-R212-AT-Commands	23
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +UCAST – Transmit A Unicast

<p>Execute Command <b>AT+UCAST:&lt;EUI64&gt;,&lt;DATA&gt;</b></p> <p>Use on All Devices</p> <p>Note</p> <ul style="list-style-type: none"> <li>- It is possible to have up to 10 transmissions to 4 different nodes in flight (i.e. pending for an ACK or NACK).</li> <li>- The ACK and/or NACK prompt can be disabled in S08</li> </ul>	<p>Response <b>+UCAST:nn</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>Where &lt;errorcode&gt; represents the error code explained in section 4.</p> <p>Prompt <b>ACK:nn</b></p> <p>or <b>NACK:nn</b></p> <p>Up to 65 bytes are sent to the node up to 6 hops away with address &lt;EUI64&gt;. On successful transmission the user is given a transmission number followed by “OK”. The user is then prompted “ACK” on receipt of an acknowledgement or “NACK” in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.</p> <p>Alternatively if bit 13 of S06 is set the response will be: <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>In this case no transmission number is issued as only a single message can be in flight. An “OK” indicates successful acknowledgement.</p>
<p>Remote action</p>	<p>Prompt</p> <p><b>UCAST:&lt;EUI64&gt;=&lt;data&gt;</b></p> <p>Where &lt;EUI64&gt; is the address of the sender.</p>
<p>SW release</p>	<p>R200</p>

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	24
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +UCASTB – Transmit A Unicast Of Binary Data

<p>Execute Command <b>AT+UCASTB:xx,&lt;EUI64&gt;</b></p> <p>Where xx is the number (in hexadecimal) of data bytes to be sent.</p> <p>Use on All Devices</p> <p>Note</p> <ul style="list-style-type: none"> <li>- This command is particularly useful if the data may contain &lt;CR&gt; and &lt;Backspace&gt; characters.</li> <li>- It is possible to have up to 10 transmissions to 4 different nodes in flight (i.e. pending for an ACK or NACK).</li> <li>- The ACK and/or NACK prompt can be disabled in S08</li> </ul>	<p>Response</p> <p><b>&gt; &lt;data being entered&gt;</b> <b>+UCAST:nn</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>Prompt</p> <p><b>ACK:nn</b></p> <p>or <b>NACK:nn</b></p> <p>Parameters</p> <p><b>xx ranging from 00 to 41 (hex)</b></p> <p>After the ‘&gt;’ prompt a number of xx characters are expected to be entered. Up to 65 bytes are sent to the node with address &lt;EUI64&gt;. In case bit D of S08 is set a timeout error is generated if no character is received for 1 second. On successful transmission the user is given a transmission number followed by “OK”. After that the user is prompted “ACK” on receipt of an acknowledgement or “NACK” in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.</p> <p>Alternatively if bit 13 of S06 is set the response will be: <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>In this case no transmission number is issued as only a single message can be in flight. An “OK” indicates successful acknowledgement.</p>
Remote action	<p>Prompt</p> <p><b>UCAST:&lt;EUI64&gt;,xx=&lt;data&gt;</b></p> <p>Where &lt;EUI64&gt; is the address of the sender and xx is the length of the message in hexadecimal</p>
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	25
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +SCAST – Transmit Data To The Sink

Execute Command <b>AT+SCAST:&lt;data&gt;</b>	Response <b>+UCAST:nn</b> <b>OK</b>
Use on All Devices	or <b>ERROR&lt;errorcode&gt;</b>
Note	Where <errorcode> represents the error code explained in section 3.
<ul style="list-style-type: none"> <li>- If a sink cannot be reached for three consecutive transmissions the sink is assumed unavailable and a new one is searched.</li> <li>- The ACK and/or NACK prompt can be disabled in S08</li> <li>- It is possible to have up to 10 transmissions in flight (i.e. pending for an ACK or NACK).</li> </ul>	Prompt <b>ACK:nn</b>
	or <b>NACK:nn</b>
	Parameters Up to 65 bytes are sent to the network's sink given it is no more than 6 hops away. On successful transmission the user is given a transmission number followed by "OK". After that the user is prompted "ACK" on receipt of an acknowledgement or "NACK" in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.
	Alternatively if bit 13 of S06 is set the response will be: <b>OK</b>
	or <b>ERROR&lt;errorcode&gt;</b>
	In this case no transmission number is issued as only a single message can be in flight. An "OK" indicates successful acknowledgement
Remote action	Prompt <b>SCAST:&lt;EUI64&gt;=&lt;data&gt;</b>
	Where <EUI64> is the address of the sender.
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	26
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +SCASTB – Transmit Binary Data To A Sink

<p>Execute Command <b>AT+SCASTB:xx</b></p> <p>Where xx is the number (in hexadecimal) of data bytes to be sent.</p> <p>Use on All Devices</p> <p>Note</p> <ul style="list-style-type: none"> <li>- If a sink cannot be reached for three consecutive transmissions the sink is assumed unavailable and a new one is searched.</li> <li>- The ACK and/or NACK prompt can be disabled in S08</li> <li>- It is possible to have up to 10 transmissions in flight (i.e. pending for an ACK or NACK).</li> </ul>	<p>Response</p> <p><b>&gt; &lt;data being entered&gt;</b> <b>+SCAST:nn</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>Parameters</p> <p><b>xx ranging from 00 to 41 (hex)</b></p> <p>After the ‘&gt;’ prompt a number of xx characters are expected to be entered. Up to 65 bytes are sent to the networks’ sink.</p> <p>In case bit D of S08 is set a timeout error is generated if no character is received for 1 second. On successful transmission the user is given a transmission number followed by “OK”. After that the user is prompted “ACK” on receipt of an acknowledgement or “NACK” in case the message was not acknowledged. A NACK does not guarantee that the message has not reached its destination.</p> <p>Alternatively if bit 13 of S06 is set the response will be: <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>In this case no transmission number is issued as only a single message can be in flight. An “OK” indicates successful acknowledgement.</p>
Remote action	<p>Prompt</p> <p><b>SCAST:&lt;EUI64&gt;,xx=&lt;data&gt;</b></p> <p>Where &lt;EUI64&gt; is the address of the sender and xx is the length of the message in hexadecimal</p>
SW release	R200

### +SSINK – Search For A Sink

<p>Read Command <b>AT+SSINK</b></p> <p>Search for a sink on the network If a sink is already known and the known sink is reporting in as a reply to this request, no prompt will be displayed.</p> <p>Use on All Devices</p>	<p>Response</p> <p><b>OK</b> or <b>ERROR&lt;errorcode&gt;</b></p> <p>Prompt</p> <p><b>SINK:&lt;EUI64&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3.</p>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	27
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### **+SINK – Display The Local Node’s Sink**

<p>Read Command <b>AT+SINK?</b></p> <p>Displays the locally stored ID of the network’s sink. In order to search for a sink use AT+SSINK.</p> <p>Use on All Devices</p>	<p>Response</p> <p><b>+SINK:Local</b> <b>OK</b></p> <p>or</p> <p><b>+SINK:None</b> <b>OK</b></p> <p>or</p> <p><b>+SINK:&lt;EUI64&gt;</b> <b>OK</b></p> <p>or</p> <p><b>ERROR&lt;errorcode&gt;</b></p> <p>Where &lt;EUI64&gt; is the address of the sink and &lt;errorcode&gt; represents the error code explained in section 3.</p>
SW release	R207

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	28
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +OPCHAN – Opens A Channel To A Remote Node

<p>Execute Command <b>AT+OPCHAN:&lt;EUI64&gt;</b></p> <p>Use on All devices</p> <p>Note Opening a channel to end devices will result in a limited data rate which depends on the polling interval of the child. When in sleep mode 02 a device will stay awake until the channel is closed</p>	<p>Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3. Once the channel is established it acts like a virtual wire and transmits any data entered bi-directionally. There is no local echo of the data entered. To close the channel enter +++ on any end of the virtual wire.</p> <p>Parameters The remote module's address &lt;EUI64&gt;.</p> <p>Examples <b>AT+OPCHAN:000D6F0000012345</b> <b>OK</b> <b>OPEN</b> <b>&gt;Hello world</b> <b>My second data line+++</b> <b>CLOSED</b></p> <p>In case the channel breaks down an error message is displayed on both ends, where &lt;errorcode&gt; represents the error code explained in section 3.</p>
<p>Remote Action</p> <p>Note The "CHAN" prompt can be disabled in register S07</p>	<p>Prompt Depending on the setting of bit 12 in the remote S06</p> <p>If unset the node will automatically accept the channel. <b>CHAN:&lt;EUI64&gt;</b> <b>OPEN</b></p> <p>if set the node will display the request in the format <b>CHAN:&lt;EUI64&gt;</b> The remote device has to acknowledge the request using the command AT+ACKCHAN command.</p>
SW release	R200

### +++ – Close Channel

<p>Execute Command <b>+++</b></p>	<p>Response <b>CLOSED</b></p>
Remote Action	<p>Prompt <b>CLOSED</b></p>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	29
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +OPLCHAN – Opens A Limited Channel To A Remote Node

Execute Command <b>AT+OPLCHAN:XXXX,&lt;EUI64&gt;</b>	Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b>
Use on All Devices	Same as AT+OPCHAN, but the connection will automatically close after a number of XXXX characters (in hexadecimal) have been sent by the device which opened the connection. +++ doesn't close the connection any more. In case Bit D of S08 is set the channel is also closed in case no character has been received via the serial port for more than a second.
Remote Action	Prompt Depending on the setting of bit 12 in the remote S06  If unset the node will automatically accept the channel. <b>LCHAN:XXXX,&lt;EUI64&gt;</b> <b>OPEN</b>  if set the node will display the request in the format <b>LCHAN:XXXX,&lt;EUI64&gt;</b> The remote device has to acknowledge the request using the command AT+ACKCHAN command.
SW release	R200

### +ACKCHAN – Accept Channel

Execute Command <b>AT+ACKCHAN:&lt;EUI64&gt;</b>	Response <b>OK</b> <b>OPEN</b>  or <b>ERROR&lt;errorcode&gt;</b>  <errorcode> represents the error code explained in section 3.
Example  Prompt <b>[L]CHAN:&lt;EUI64&gt;</b>  Reply <b>AT+ACKCHAN:&lt;EUI64&gt;</b>	The unit gets prompted that a remote unit is trying to establish a channel to this unit.  If required the channel can be acknowledged which will cause the channel to open.  In S06 the unit can be configured to automatically accept every incoming channel if not connected to another active channel.
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	30
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### +RDATA – Send Binary Raw Data

<p>Execute Command <b>AT+RDATA:xx</b></p> <p>Use on All Devices</p> <p>Note Can be useful to quickly exchange bulk data with neighbouring node. The application needs to handle addressing, error checking, retries and acknowledgements.</p>	<p>Response <b>&gt; &lt;data being entered&gt;</b> <b>OK</b></p> <p>or <b>ERROR&lt;errorcode&gt;</b></p> <p>Parameters <b>xx ranging from 00 to 72 (hex)</b></p> <p>After the ‘&gt;’ prompt a number of xx characters are expected to be entered. Up to 114 bytes of data can be send to all nodes within reach (direct neighbours) The data is neither encrypted nor error checked. No retries are made and no acknowledgement is received.</p> <p>&lt;errorcode&gt; represents the error code explained in section 3.</p>
Remote action	<p>Prompt <b>RAW:&lt;data&gt;</b></p> <p>or</p> <p><b>&lt;data&gt;</b></p> <p>in case bit B of S08 is set. Also this prompt can be disabled entirely by setting bit A of S08.</p>
SW release	R208

### +IDENT – Play A Tune On Remote Devboard

<p>Execute Command <b>AT+IDENT:&lt;EUI64&gt;</b></p> <p>Use on All Devices</p>	<p>Response <b>OK</b> or <b>ERROR&lt;errorcode&gt;</b></p> <p>&lt;errorcode&gt; represents the error code explained in section 3. Plays a tune on a remote devboard if the Beeper is connected. Useful to identify remote nodes. See devkit manual for details about connecting a beeper to the ETRX1 and ETRX2. Setting bit 0 in S08 disables the remote response to the AT+IDENT command. The tune played on the remote device will differ depending on whether the device is an ETRX1 or ETRX2.</p>
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	31
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### 3 List of Error codes

01	Too many characters have been entered on the command line
02	Unknown command
04	Invalid S-Register
05	Invalid parameter
06	Unicast could not be sent
07	Message was not acknowledged
08	No sink known
0E	Channel is unavailable
0F	Fatal error initialising the network
10	Error bootloading
12	Fatal error initialising the stack
14	Binding problem
15	Channel failed
16	Error trying to acknowledge a channel, which has not been requested recently
17	Only allowed on end devices
18	Out of buffers
19	Trying to write read-only register
20	Invalid password
23	PWM not in use (ETRX1 only)
24	Error Polling from Parent
25	Cannot form network
26	Cannot join network
27	No network found
28	Operation cannot be completed if node is part of a PAN
29	Local device is sink
2A	Error during energy scan
2B	No free Bindings
2C	Error leaving the PAN
2D	Error scanning for PANs
2F	Polling parent unsuccessful
30	Trying to clone or passthrough to an incompatible hardware platform
33	No response from the remote bootloader (ETRX2)
34	Target did not respond during cloning (ETRX2)
35	Timeout occurred during xCASTB
40	UART RX Frame error
41	UART RX Parity error
42	UART TX software buffer overflow
43	UART RX software buffer overflow
44	UART RX hardware buffer overflow
6C	Invalid binding table index
72	the maximum number of in flight messages has been exceeded
74	Payload too long
91	Operation only possible if joined to a PAN
A1	Network overload

Telegesis		TG-ETRX-R212-AT-Commands	32
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 4 S-Registers

Most S-Registers of the ETRX1 and ETRX2 can be read and written locally as well as remotely. The S-Registers are summarised in the table below.

S-Register Overview		Local R/W	Remote R/W
<b>S00</b>	Channel Mask	(•/•)	(•/•)
<b>S01</b>	Preferred PAN ID	(•/•)	(•/•)
<b>S02</b>	Transmit Power Level	(•/•)	(•/•)
<b>S03</b>	Encryption key <sup>1</sup>	(-/•)	(-/•)
<b>S04</b>	User Definable name	(•/•)	(•/•)
<b>S05</b>	OEM Word <sup>1</sup>	(•/•)	(•/•)
<b>S06</b>	Main Function <sup>1</sup>	(•/•)	(•/•)
<b>S07</b>	Extended Function1	(•/•)	(•/•)
<b>S08</b>	Extended Function2	(•/•)	(•/•)
<b>S09</b>	Password <sup>1</sup>	(-/•)	(-/•)
<b>S0A</b>	Revision Number	(•/•)	(•/•)
<b>S0B</b>	UART Setup	(•/•)	(•/•)
<b>S0C</b>	ETRX2: Pull-up enable ETRX1: Reserved	(•/•)	(•/•)
<b>S0D</b>	Data Direction of I/O Port (DDR) <b>(volatile)</b>	(•/•)	(•/•)
<b>S0E</b>	Initial value of S0D	(•/•)	(•/•)
<b>S0F</b>	Output Buffer of I/O Port (PORT) <b>(volatile)</b>	(•/•)	(•/•)
<b>S10</b>	Initial value of S0F	(•/•)	(•/•)
<b>S11</b>	Input Buffer of I/O Port (PIN) <b>(volatile)</b>	(•/-)	(•/-)
<b>S12</b>	A/D1	(•/-)	(•/-)
<b>S13</b>	A/D2	(•/-)	(•/-)
<b>S14</b>	ETRX2: A/D3 (Reserved) ETRX1: Reserved	(•/-)	(•/-)
<b>S15</b>	Immediate functionality at IRQ0	(•/•)	(•/•)
<b>S16</b>	Immediate functionality at IRQ1	(•/•)	(•/•)
<b>S17</b>	Timer/Counter 0	(•/•)	(•/•)
<b>S18</b>	Functionality for Timer/Counter 0	(•/•)	(•/•)
<b>S19</b>	Timer/Counter 1	(•/•)	(•/•)
<b>S1A</b>	Functionality for Timer/Counter 1	(•/•)	(•/•)
<b>S1B</b>	Timer/Counter 2	(•/•)	(•/•)
<b>S1C</b>	Functionality for Timer/Counter 2	(•/•)	(•/•)
<b>S1D</b>	Timer/Counter 3	(•/•)	(•/•)
<b>S1E</b>	Functionality for Timer/Counter 3	(•/•)	(•/•)
<b>S1F</b>	Timer/Counter 4	(•/•)	(•/•)
<b>S20</b>	Functionality for Timer/Counter 4	(•/•)	(•/•)
<b>S21</b>	Timer/Counter 5	(•/•)	(•/•)
<b>S22</b>	Functionality for Timer/Counter 5	(•/•)	(•/•)
<b>S23</b>	Timer/Counter 6	(•/•)	(•/•)
<b>S24</b>	Functionality for Timer/Counter 6 <b>(volatile)</b>	(•/•)	(•/•)

<sup>1</sup> Access to these registers is password protected

Telegesis		TG-ETRX-R212-AT-Commands	33
ETRX1 and ETRX2		AT-Command Dictionary	2.12

<b>S-Register Overview (continued)</b>		<b>Local R/W</b>	<b>Remote R/W</b>
<b>S25</b>	Initial Functionality for Timer/Counter 6	(●/●)	(●/●)
<b>S26</b>	Timer/Counter 7	(●/●)	(●/●)
<b>S27</b>	Functionality for Timer/Counter 7 ( <b>volatile</b> )	(●/●)	(●/●)
<b>S28</b>	Initial Functionality for Timer/Counter 7	(●/●)	(●/●)
<b>S29</b>	Power mode ( <b>volatile</b> )	(●/●)	(●/●)
<b>S2A</b>	Initial Power Mode	(●/●)	(●/●)
<b>S2B</b>	Start-up Functionality Plaintext A	(●/●)	(●/●)
<b>S2C</b>	Start-up Functionality Plaintext B	(●/●)	(●/●)
<b>S2D</b>	Parent's EUI	(●/-)	(●/-)
<b>S2E</b>	Device Specific	(●/●)	(●/●)
<b>S2F</b>	Special Function Pin 1 ( <b>volatile</b> )	(●/●)	(●/●)
<b>S30</b>	Initial value of S2F	(●/●)	(●/●)
<b>S31</b>	Special Function Pin 2 ( <b>volatile</b> ) (ETRX2 only)	(●/●)	(●/●)
<b>S32</b>	Initial value of S31 (ETRX2 only)	(●/●)	(●/●)
<b>S33</b>	Supply Voltage (ETRX2 only)	(●/-)	(●/-)

**Table 6: S-Register Overview**

With a few exceptions the S-registers are stored in non-volatile memory and will keep their user defined settings unless reset to the factory defaults using the "AT&F" command. S0D, S0F, S27, S29, S2F and S31 are directly accessing volatile I/O registers to prevent memory corruption due to constant I/O access. Registers S0E, S10, S28, S2A, S30 and S32 represent the non-volatile registers which define the contents of S0D, S0F, S27, S29, S2F and S31 respectively after booting up.

#### 4.1 Recovery of the Factory Default Settings

If the unit seems to be unresponsive to commands on the serial port this is most often due to the unit having been set into a power-down mode or the set-up for the serial connection having been altered. With revisions R200 of the firmware upwards, a feature has been added which performs a factory reset on any module which seems unresponsive. To factory reset a module, connect it to the PC's serial port and execute the Factory Reset Tool (downloadable from [www.telegesis.com](http://www.telegesis.com)). When pressing the Reset button on the Reset Tool you are prompted to cause a hardware reset to the module by pulling the modules' reset line low for more than 100ms (done by pressing the reset button on the Development Board). Once completed, the factory default settings of the ETRXn module are restored.

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	34
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 4.2 S-Registers for Radio Setup

### S00 – Channel Mask

<p>Description The 802.15.4 channel mask.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective When Joining, Scanning or establishing a PAN</p> <p>Note The channel mask does not affect the AT+JPAN command</p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit decimal number enabling IEEE802.15.4 channel numbers 11 to 26. Writing a bit to 1 enables a channel and subsequently writing a bit to 0 disables a channel for scanning, joining and establishing networks. e.g. when setting S00 to 0001, only channel 11 will be used for all following operations.</p> <p>Range <b>0001 - FFFF</b></p> <p>Factory Default <b>FFF0</b></p> <p>Default changed in R210</p>
--	---

### S01 – Preferred PAN ID

<p>Description The 802.15.4 PAN ID.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective When Joining or establishing a PAN</p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit decimal number</p> <p>Range <b>0000 – 3FFF or FFFF</b></p> <p>When establishing a PAN the coordinator will pick a random PAN ID if S01 is set to FFFF. If set to any value between 0000 and 3FFF this number will be used as PAN ID instead, unless trying to establish a PAN which already exists on the same channel. In this case a random PAN ID will be used instead.</p> <p>When joining only PANs with the ID stored in S01 will be joined unless S01 is set to FFFF. In this case the next best PAN which allows joining is joined.</p> <p>Factory Default <b>FFFF</b></p> <p>R200</p>
---	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	35
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S02 – Transmit Power Level

<p>Description The devices transmit power level in dBm.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective When Joining or establishing a PAN</p> <p>Storage <b>Non-Volatile</b></p>	<p>Parameters <b>snn</b></p> <p>Where snn represents a signed 8-bit decimal number.</p> <p>Range <b>-1 to -32</b> (on ETRX1) <b>4 to -43</b> (on ETRX2)</p> <p>Setting S02 to 4 on the ETRX2 enables the radio boost mode increasing both output power as well as sensitivity. Actual values for the ETRX2 are {3, 2, 1, -1, -2, -3, -4, -5, -6, -7, -8, -9, -11, -12, -14, -17, -20, -26, -43} Entering a value not on this list (such as -19) will result in the next lowest output power.</p> <p>Factory Default <b>-1</b> (on ETRX1) <b>3</b> (on ETRX2)</p>
SW release	R208

### S03 – Encryption Key

<p>Description The encryption key which can be written using the password. The default password on both ETRX1 and ETRX2 is "TG-ETRX1".</p> <p>Operations <b>W LOCAL</b> <b>W REMOTE</b></p> <p>Write operation <b>ATS03=&lt;key&gt;:&lt;password&gt;</b> <b>ATSREM03:&lt;EUI64&gt;=&lt;key&gt;:&lt;password&gt;</b></p> <p>Becomes effective When Joining or establishing a PAN</p> <p>Storage <b>Non Volatile</b></p>	<p>Range <b>From 0 to 2<sup>128</sup>-1</b></p> <p>The 128-bit AES encryption key in hexadecimal representation (32 characters).</p> <p>For an in depth description of the network establishment and maintenance please refer to the user guide.</p> <p>When set to all 0s (default) a random security key is generated when establishing a PAN.</p> <p>Factory Default <b>00000000000000000000000000000000</b></p>
SW release	R208 added random key generation

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	36
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### 4.3 S-Registers for Module Setup

#### S04 – User Readable Name

<p>Description A Used defined name which can be used to identify the node</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>CCCCCCCCCCCCCCCCCCCC</b></p> <p>Name with up to 20 characters.</p> <p>Factory Default <b>&lt;none&gt;</b></p> <p>R208 – removed default setting</p>
---	--

#### S05 – OEM Word

<p>Description Password protected 16 bits which can be written by the OEM for device identification. The default password on both ETRX1 and ETRX2 is “TG-ETRX1”.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Write operation <b>ATS05=XXXX:&lt;password&gt;</b> <b>ATSREM55:&lt;EUI64&gt;=XXXX:&lt;password&gt;</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p><b>Bit 15 (MSB) – Bit 0:</b> OEM Defined</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	37
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S06 – Main Function

<p>Description Defines the behaviour of the Device.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Write operation <b>ATS06=XXXX:&lt;Password&gt;</b> <b>ATSREM06:&lt;EUI64&gt;=xxxx: &lt;Password&gt;</b></p> <p>Note</p> <ul style="list-style-type: none"> <li>- Default settings are underlined</li> <li>- For security reasons this register is password protected. The default password on both ETRX1 and ETRX2 is “TG-ETRX1”.</li> <li>- Changes to Bits 9 and 10 require leaving and joining the network again to take effect.</li> <li>- An end device cannot be a sink</li> </ul> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p><b>Bit F:</b> Read only. Set: Brownout Fuse is not set. (ETRX1 only, reserved on ETRX2)</p> <p><b>Bit E:</b> Set: Remote S-Register Reads don't wait for ACK</p> <p><b>Bit D:</b> Set: UCASTs and SCASTs wait for ACK</p> <p><b>Bit C:</b> Set: Prompt user if a channel has been requested. <u>Unset:</u> Automatically accept channel</p> <p><b>Bit B:</b> Set: Joining not permitted (overrides bits 0-3)</p> <p><b>Bit A:</b> Set: Moving End Device (MED). <u>Unset:</u> Sleepy End Device (SED) (note: bit 9 must also be set)</p> <p><b>Bit 9:</b> Set: Device is an End Device (bit A specifies Sleepy or Moving End Device)</p> <p><b>Bit 8:</b> Device is Data Sink</p> <p><b>Bit 7:</b> Set: Writing to S03 takes effect immediately (device will do a quick leave/re-init)</p> <p><b>Bit 6:</b> Set: Display RSSI and LQI when devices report to AT+SN and AT+REMSN or AT+PING in</p> <p><b>Bit 5:</b> Set: Attach Vcc reading to transmissions for functionalities 0100-0103, 0110-0113 and 2000</p> <p><b>Bit 4:</b> Set: When trying to join a network use network key in S03 (secured joining)</p> <p><b>Bit 3:</b> <u>Set:</u> Allow unsecured joining via local node</p> <p><b>Bit 2:</b> Set: Allow secured joining via local node</p> <p><b>Bit 1:</b> <u>Set:</u> Allow unsecured joining via Trust Centre</p> <p><b>Bit 0:</b> Set: Allow secured joining via Trust Centre</p> <p>Factory Default <b>000C</b></p> <p>R200</p>
---	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	38
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S07 – Extended Function1

<p>Description Defines the behaviour of the Device.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p><b>Bit F:</b> Set: Disable &lt;plaintext&gt; prompt  <b>Bit E:</b> Set: Disable SDATA / NDATA prompts  <b>Bit D:</b> Set: Disable COUNT: prompt  <b>Bit C:</b> Set: Disable xED:, FFD: and COO: prompts  <b>Bit B:</b> Set: Disable UCAST:&lt;EUI64&gt; prefix  <b>Bit A:</b> Set: Disable BCAST:&lt;EUI64&gt; prefix  <b>Bit 9:</b> Set: Disable SCAST:&lt;EUI64&gt; prefix  <b>Bit 8:</b> Set: Disable '&gt;' prompt when sending BCASTB, SCASTB, RDATAB, UCASTB.  <b>Bit 7:</b> Set: Disable SCAST prompt  <b>Bit 6:</b> Set: Disable BCAST prompt  <b>Bit 5:</b> Set: Disable UCAST prompt  <b>Bit 4:</b> Set: Disable JPAN prompt  <b>Bit 3:</b> Set: Disable LeftPAN prompt  <b>Bit 2:</b> Set: Disable CHAN prompt  <b>Bit 1:</b> Set: Disable NEWNODE prompt  <b>Bit 0:</b> Set: Disable SINK prompt</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
---	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	39
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S08 – Extended Function2

<p>Description Defines the behaviour of the Device.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p><b>Bit F:</b> Set: Changes to S02 take effect immediately  <b>Bit E:</b> Set: I/O7 is driven high if awake and driven low otherwise (must be set as output)  <b>Bit D:</b> Set: Enable 1s character timeout when entering data for xCASTB and limited channel.  <b>Bit C:</b> Set: Don't discard and search for new sink when unreachable for three consecutive times  <b>Bit B:</b> Set: Do not encapsulate raw data on rec.  <b>Bit A:</b> Set: Disable displaying RAW: prompts  <b>Bit 9:</b> Set: Disable ERROR:xx prompt  <b>Bit 8:</b> Set: Disable OK prompt  <b>Bit 7:</b> Set: Disable UCAST[B]:xx prompt  <b>Bit 6:</b> Set: Disable SCAST[B]:xx prompt  <b>Bit 5:</b> Set: Disable CLOSED prompt  <b>Bit 4:</b> Set: Disable OPEN prompt  <b>Bit 3:</b> Set: Enable PWRCHANGE:nn prompt  <b>Bit 2:</b> Set: Disable NACK:nn prompt  <b>Bit 1:</b> Set: Disable ACK:nn prompt  <b>Bit 0:</b> Set: Disable AT+IDENT tune</p> <p>Factory Default <b>0000</b></p> <p>Last modified in R205</p>
---	---

### S09 – Password

<p>Description The local nodes password.</p> <p>Operations <b>W LOCAL</b> <b>W REMOTE</b></p> <p>Write operation <b>ATS09=&lt;NEW&gt;:&lt;OLD&gt;</b> <b>ATSREM09:&lt;EUI64&gt;=&lt;NEW&gt;:&lt;OLD&gt;</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>CCCCCCCC</b></p> <p>8 case sensitive characters (8 bytes). Note that the password <b>must</b> have exactly 8 characters.</p> <p>Factory Default <b>TG-ETRX1</b></p> <p>R200</p>
--	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	40
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S0A – Revision number

Description The firmware revision number.	Parameters The firmware revision number
Operations <b>R LOCAL</b> <b>R REMOTE</b>	
Becomes effective <b>Instantly</b>	
Storage <b>Non-Volatile</b>	
SW release	R200

Telegesis		TG-ETRX-R212-AT-Commands	41
ETRX1 and ETRX2		AT-Command Dictionary	2.12

#### 4.4 I/O related S-Registers

##### S0B – UART Setup

<p><b>Description</b> The device's RS232 Baudrate and mode. The default setting of 0500 results in: 19200bps, no parity, 1 stop bit, 8 data bits.</p> <p><b>Operations</b> <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective Instantly</p> <p><b>Note</b> For the ETRXn Ember only guarantees proper operation of the stack up to 19200 baud. It is not recommended to use continuous data rates above 38400, even using hardware flow control as using higher data rates does not increase the actual throughput. If bit 5 is set, bi-directional Hardware Flow Control is used instead of XON/XOFF flow control. If using Hardware flow control I/O4 becomes the RTS output and the CTS input is assigned to either</p> <p><b>I/O3 (ETRX1)</b> <b>I/O2 (ETRX2)</b></p> <p>On the ETRX1 the CTS input can be moved to I/O2 for compatibility reasons by setting bit 7 of this register.</p> <p>Access to these I/Os via S0D,S0F is blocked whilst Hardware Flow control is active. Note that in case the 128-byte output buffer of the ETRXn is full data will be dropped.</p> <p><b>Storage</b> <b>Non-Volatile</b> SW release</p>	<p><b>Parameters</b> <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range of the most significant byte <b>00 to 0C</b></p> <p>00: 1200 baud 01: 2400 baud 02: 4800 baud 03: 9600 baud 04: 14400 baud 05: 19200 baud 06: 28800 baud 07: 38400 baud 08: 50000 baud 09: 57600 baud 0A: 76800 baud 0B: 100000 baud 0C: 115200 baud (ETRX2 only)</p> <p>Range of the least significant byte <b>00 to FF</b></p> <p>bit 7 set: CTS is on I/O2 (ETRX1 only, ETRX2: reserved) bit 6 set: enable error prompts for parity error, rx-frame-error and rx-buffer overflow bit 5 set: H/W flow control enable bit 4 set: no command echo bit 3 set: 7 data bits instead of 8 bit 2 set: 2 stop bits instead of one bit 1 set: odd parity enabled bit 0 set: even parity enabled</p> <p><b>Factory Default</b> <b>0500</b> Modified in R208</p>
--	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	42
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S0C – ETRX2: Pull-up enable ETRX1: Reserved

<p>Description Allows to enable the built in pull-ups for each individual I/O pin of the ETRX2.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective Instantly</p> <p>Note To achieve ultra low current consumption it is recommended not to use the built in pull-ups and leave this register in its default state.</p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p>representing I/O pins xxxx BA98 7654 3210 (ETRX2)</p> <p>e.g. setting bit 7 to 1 will enable the pull-up for I/O pin 7</p> <p>Factory Default <b>0000</b></p> <p>Added in R209</p>
--	--

### S0D – Data Direction of I/O Port

<p>Description The data direction of the module's I/O port</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective Instantly</p> <p>Storage <b>Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p>representing I/O pins xxxx xxxx 7654 3210 (ETRX1) xxxx BA98 7654 3210 (ETRX2)</p> <p>e.g. setting bit 7 to 1 will turn I/O pin 7 into an output, setting it to 0 will make it an input respectively.</p> <p>Factory Default <b>Defined in S0E</b></p> <p>R200</p>
---	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	43
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S0E – Initial Setting of S0D

<p>Description The initial setting of S0D stored in non volatile memory</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective After Soft or Hard Reset</p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents the initial value of S0D which is loaded after boot-up, soft or hard reset.</p> <p>Factory Default <b>00F8</b></p> <p>R200</p>
---	---

### S0F – Output Buffer Of I/O Port

<p>Description The output buffer of the module's I/O port</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p>Range <b>0000 to FFFF</b></p> <p>representing I/O pins xxxx xxxx 7654 3210 (ETRX1) xxxx BA98 7654 3210 (ETRX2)</p> <p>If the I/O pin has been defined as an output in S0D the pin will drive the logic level defined by S0F. On the ETRX1 if defined as an input setting the output buffer to 1 activates the internal pull-up, which should be avoided if power consumption is critical.</p> <p>Factory Default <b>Defined in S10</b></p> <p>R200</p>
---	---

### S10 – Initial Setting of S0F

<p>Description The initial setting of S0F stored in non volatile memory</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>After Soft or Hard Reset</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents the initial value of S0F which is loaded after boot-up, soft or hard reset.</p> <p>Factory Default <b>00F0</b></p> <p>R200</p>
--	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	44
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S11 – Input Buffer of I/O Port

<p>Description The Logical Levels at the I/O Pins</p> <p>Operations <b>R LOCAL</b> <b>R REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Instant Reading of Port Status</b></p> <p>SW release</p>	<p>Range <b>0000 to FFFF</b></p> <p>representing I/O pins xxxx xxxx 7654 3210 (ETRX1) xxxx BA98 7654 3210 (ETRX2)</p> <p>S11 represents the logic level at each pin of the I/O port.</p> <p>R200</p>
---	--

### S12 – A/D1 Reading

<p>Description The analogue reading of A/D1</p> <p>Operations <b>R LOCAL</b> <b>R REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Instant Reading of analogue input</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Representation The hexadecimal reading of the analogue input in mV with respect to ground.</p> <p>Range ETRX1: 0000 – 09F6 (0 – 2550) ETRX2: 0000 – 04B0 (0 – 1200)</p> <p>If bit E of S2E is set on the ETRX1 the reading represents the contents of the 10-bit ADC register.</p> <p>R209</p>
--	---

### S13 – A/D2 Reading

<p>Description The analogue reading of A/D2</p> <p>Operations <b>R LOCAL</b> <b>R REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Instant Reading of analogue input</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>Representation The hexadecimal reading of the analogue input in mV with respect to ground.</p> <p>Range ETRX1: 0000 – 09F6 (0 – 2550) ETRX2: 0000 – 04B0 (0 – 1200)</p> <p>If bit E of S2E is set on the ETRX1 the reading represents the contents of the 10-bit ADC register.</p> <p>R209</p>
--	---

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	45
ETRX1 and ETRX2		AT-Command Dictionary	2.12

#### **S14 – A/D3 Reading (ETRX2 only when bit 7 of S2F is set, reserved otherwise)**

Description	Parameters
The analogue reading of A/D2	<b>XXXX</b>
Operations	Representation
<b>R LOCAL</b>	The hexadecimal reading of the analogue input in mV with respect to ground. The return value will be 0xFFFF in case A/D3 has not been enabled by setting bit 7 of S2E.
<b>R REMOTE</b>	
Becomes effective	Range
<b>Instantly</b>	ETRX2: 0000 – 04B0 (0 – 1200)
Storage	
<b>Instant Reading of analogue input</b>	
SW release	R209

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	46
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 4.5 S-Registers Defining the Functionality of the Module

There are 10 events which can trigger a user-selectable action to prevent the need for a host microcontroller for simple applications. Two out of those 10 events are the two external interrupts which can be enabled in Register S2E. The actions to be performed on those two interrupt events are defined in S15 and S16. The user can pick any of the actions from the list in section 5 of this document and assign them to any event.

The remaining 8 events are timed events. Registers S17 to S28 control those 8 timers and their corresponding events. Please note that the first 4 timers are used by default for network management tasks, which can be modified by the user when changing the corresponding registers. A timer will increment every 250ms (4 times a second) and when the timer reaches the value stored in the timer/counter register the corresponding action will be executed.

### S15 – Immediate Functionality At IRQ0

Description Describes the immediate action taken on IRQ0.	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.
Becomes effective <b>Instantly</b>	
Storage <b>Non-Volatile</b>	Factory Default <b>0001 (Wakeup to power mode 0)</b>
SW release	R200

### S16 – Immediate Functionality At IRQ1

Description Describes the immediate action taken on IRQ1.	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.
Becomes effective <b>Instantly</b>	
Storage <b>Non-Volatile</b>	Factory Default <b>0001 (Wakeup to power mode 0)</b>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	47
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S17 –Timer/Counter 0

<p>Description A multi purpose Timer/Counter which functionality is defined by S18</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>0004 (1s interval)</b></p> <p>R200</p>
--	--

### S18 – Functionality For Timer/Counter 0

<p>Description Defines the functionality for Timer/Counter 0 events.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0011 (end devices poll parent)</b></p> <p>R200</p>
--	--

### S19 –Timer/Counter 1

<p>Description A multi purpose Timer/Counter which functionality is defined by S1A</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>00F0 (1 min interval)</b></p> <p>R200</p>
--	---

Telegesis		TG-ETRX-R212-AT-Commands	48
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S1A – Functionality For Timer/Counter 1

Description Defines the functionality for Timer/Counter 1 events.	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.
Becomes effective <b>Instantly</b>	
Storage <b>Non-Volatile</b>	Factory Default <b>0013 (sink advertisement)</b>
SW release	R200

### S1B –Timer/Counter 2

Description A multi purpose Timer/Counter which functionality is defined by S1C	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed.
Becomes effective <b>Instantly</b>	If set to 0 the corresponding functionality is disabled.
Storage <b>Non-Volatile</b>	Factory Default <b>00F4 (1 min 1s interval)</b>
SW release	Changed in R208

### S1C – Functionality For Timer/Counter 2

Description Defines the functionality for Timer/Counter 2 events.	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.
Becomes effective <b>Instantly</b>	
Storage <b>Non-Volatile</b>	Factory Default <b>0014 (leave network if I am alone)</b>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	49
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S1D –Timer/Counter 3

<p>Description A multi purpose Timer/Counter which functionality is defined by S1E</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>00F0 (1min interval)</b></p> <p>R200</p>
--	--

### S1E – Functionality For Timer/Counter 3

<p>Description Defines the functionality for Timer/Counter 3 events.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0016 (if not part of a network do AT+JN)</b></p> <p>R200</p>
--	--

### S1F –Timer/Counter 4

<p>Description A multi purpose Timer/Counter which functionality is defined by S20</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	50
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S20 – Functionality For Timer/Counter 4

<p>Description Defines the functionality for Timer/Counter 4 events.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

### S21 –Timer/Counter 5

<p>Description A multi purpose Timer/Counter which functionality is defined by S22</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

### S22 – Functionality For Timer/Counter 5

<p>Description Defines the functionality for Timer/Counter 5 events.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	51
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S23 –Timer/Counter 6

<p>Description A multi purpose Timer/Counter which functionality is defined by S24</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

### S24 –Functionality For Timer/Counter 6

<p>Description Defines the functionality for Timer/Counter 6 events.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

### S25 – Initial Functionality For Timer/Counter 6

<p>Description Defines the setting of S24 after power up or reset.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>After hard or soft reset</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
---	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	52
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S26 –Timer/Counter 7

<p>Description A multi purpose Timer/Counter which functionality is defined by S27</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>A 16-bit hexadecimal number representing a threshold for either a timer or counter event to be triggered. When reading this register the threshold rather than the actual timer/counter value is displayed. If set to 0 the corresponding functionality is disabled.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

### S27 – Functionality For Timer/Counter 7

<p>Description Defines the functionality for Timer/Counter 7 events.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
--	--

### S28 – Initial Functionality For Timer/Counter 7

<p>Description Defines the setting of S27 after power up or reset.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>After hard or soft reset</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>XXXX</b></p> <p>If set to 0 the functionality is disabled. Please see section 5 for a list of the functionality.</p> <p>Factory Default <b>0000</b></p> <p>R200</p>
---	--

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	53
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S29 – Power Mode

Description The current power mode of the module	Parameters <b>nn</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	Range <b>00 – 03</b>
Becomes effective <b>Instantly</b>	The modules power level as described in section 6.
Storage <b>Volatile</b>	Factory Default <b>Defined in S2A</b>
SW release	R200

### S2A – Initial Power Mode

Description The module's power mode after start-up and reset.	Parameters <b>nn</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	Range <b>00 – 03</b>
Becomes effective <b>After hard or soft reset</b>	The modules power level as described in section 6.
Storage <b>Non-Volatile</b>	Factory Default <b>00</b>
SW release	R200

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	54
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S2B – Start-up Functionality Plaintext A

<p>Description Contains Text which is used by some of the actions described in section 5.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>Up to 50 characters</b></p> <p>Factory Default <b>&lt;none&gt;</b></p> <p>R208 – removed default setting</p>
---	---

### S2C – Start-up Functionality Plaintext B

<p>Description Contains Text which is used by some of the actions described in section 5.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Storage <b>Non-Volatile</b></p> <p>SW release</p>	<p>Parameters <b>Up to 50 characters</b></p> <p>Factory Default <b>&lt;none&gt;</b></p> <p>R208 – removed default setting</p>
---	---

### S2D – Parent’s EUI64

<p>Description Contains the local unit’s parent EUI64 in case the unit is a SED or MED</p> <p>Operations <b>R LOCAL</b> <b>R REMOTE</b></p> <p>Storage <b>Stack Parameter</b></p> <p>SW release</p>	<p>Parameters <b>&lt;n/a&gt;</b></p> <p>if the device isn’t a SED or MED, or</p> <p><b>&lt;EUI64&gt;</b></p> <p>R200</p>
---	--

Telegesis		TG-ETRX-R212-AT-Commands	55
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 4.6 Device Specific S-Registers

S2E – Device Specific	
<p>Description Defines the behaviour of the specific device. Functionality differs between ETRX1 and ETRX2.</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>Instantly</b></p> <p>Note Default settings are underlined</p> <p>Storage <b>Non-Volatile</b></p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents a 16-bit hexadecimal number.</p> <p><b><u>ETRX1:</u></b></p> <p><b>Bit F (MSB):</b> Set: Behaviour of I/O3 is defined by S2F. <u>Unset:</u> Standard I/O pin.  <b>Bit E:</b> Set: A/D readings from S12 and S13 represent the 10-bit reading rather than the voltage  <b>Bit D:</b> Set: Pull-ups enabled globally  <b>Bit C – Bit 5:</b> Reserved  <b>Bit 4:</b> Set: Enable debouncing on IRQ pins(100ms)  <b>Bit 3:</b> Set: IRQ1 on rising edge  <b>Bit 2:</b> Set: IRQ1 on falling edge  <b>Bit 1:</b> Set: IRQ0 on rising edge  <b>Bit 0:</b> Set: IRQ0 on falling edge</p> <p><b><u>ETRX2:</u></b></p> <p><b>Bit F (MSB):</b> Set: I/O3 is PWM as defined by S2F/S31. <u>Unset:</u> Standard I/O pin.  <b>Bit E – Bit D:</b> Reserved  <b>Bit C:</b> Set: Transmitter adds PAN ID to raw data packets. Receiver ignores packets with wrong ID  <u>Unset:</u> PAN ID not used with raw data, devices in all PANs on the same radio channel receive data  <b>Bit B – Bit 9:</b> Reserved  <b>Bit 8:</b> Set: Enable Boost mode regardless of setting in S02  <b>Bit 7:</b> Set: I/O8 turns into A/D3, which can be read from S14  <b>Bit 6:</b> Set: Present A/D-Reference at I/O0 during measurement  <b>Bit 5:</b> Set: Enable wakeup on UART activity  <b>Bit 4:</b> Set: Enable debouncing on IRQ pins(100ms)  <b>Bit 3:</b> Set: IRQ1 on rising edge  <b>Bit 2:</b> <u>Set:</u> IRQ1 on falling edge  <b>Bit 1:</b> Set: IRQ0 on rising edge  <b>Bit 0:</b> <u>Set:</u> IRQ0 on falling edge</p> <p>Factory Default <b>0005</b></p>
SW release	Last modified in R209

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	56
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S2F – Operation of the special function pin 1

<p>Description The mode of operation for the special function pin</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Operations <b>Instantly</b></p> <p>Storage <b>Volatile</b></p>	<p>Parameters <b>XXXX</b></p> <p>Range <b>0000 to FFFF</b></p> <p><b><u>ETRX1</u></b></p> <p>If the special function pin is enabled by setting bit 15 of S2E, the first byte of S2F is written to the OCR2 register of the Atmega128 and the second byte of S2F is written to the TCCR2 register of the Atmel AtMega 128L. This allows I/O3 to output a PWM or constant carrier signal. For more information see the Atmega128 datasheet.</p> <p><b><u>ETRX2</u></b></p> <p>This register represents the top value of the 16-bit counter counting from 0 to top repeatedly incrementing at 12MHz. When reaching top I/O3 is set, given the PWM is enabled in S2E.</p> <p>Factory Default <b>Defined in S30</b></p>
<p>Examples See User Guide</p>	
<p>SW release</p>	<p>R200</p>

### S30 – Initial value of S2F

<p>Description The initial setting of S2F stored in non volatile memory</p> <p>Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b></p> <p>Becomes effective <b>After Soft or Hard Reset</b></p> <p>Storage <b>Non-Volatile</b></p>	<p>Parameters <b>XXXX</b></p> <p>Where XXXX represents the initial value of S2F which is loaded after boot-up, soft or hard reset.</p> <p>Factory Default <b>ETRX1: 4D1B (800Hz 50% m/s ratio)</b> <b>ETRX2: 3A98 (800Hz 50% m/s ratio)</b></p>
<p>SW release</p>	<p>R200</p>

Telegesis		TG-ETRX-R212-AT-Commands	57
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### S31 – Operation Of The Special function Pin 2 (ETRX2 only – reserved on ETRX1)

Description The mode of operation for the special function pin	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	Range <b>0000 to FFFF</b>
Operations <b>Instantly</b>	<b><u>ETRX2</u></b>
Storage <b>Volatile</b>	If the special function pin is enabled by setting bit 15 of S2E, this register represents the compare value of the 16-bit counter counting from 0 to top repeatedly incrementing at 12MHz. When reaching compare I/O3 is cleared.
	Factory Default <b>Defined in S32</b>
SW release	R203 (ETRX2 only)

### S32 – Initial Value S31 (ETRX2 only – Reserved on ETRX1)

Description The initial setting of S31 stored in non volatile memory	Parameters <b>XXXX</b>
Operations <b>R/W LOCAL</b> <b>R/W REMOTE</b>	Where XXXX represents the initial value of S31 which is loaded after boot-up, soft or hard reset.
Becomes effective <b>After Soft or Hard Reset</b>	
Storage <b>Non-Volatile</b>	Factory Default <b>1D4C (800Hz 50% m/s ratio)</b>
SW release	R203 (ETRX2 only)

### S33 – Supply Voltage

Description The Supply voltage of the device in mV.	Parameters <b>nnnn</b>
Operations <b>R LOCAL</b> <b>R REMOTE</b>	Where nnnn represents the supply voltage in mV.
Becomes effective <b>N/A</b>	
Storage <b>Volatile</b>	Factory Default <b>N/A</b>
SW release	R204 (ETRX2 only)

Telegesis		TG-ETRX-R212-AT-Commands	58
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 5 Built in Functionality

The following table gives an overview of the built-in functionality which can be triggered either by the two external interrupts IRQ0 and IRQ1 or by 8 individually programmable timers/counters. If the node is in a low power mode and the action requires the node to wakeup, the node will do so and go back to its original power mode after completion of the action. To get more information on the built-in functionality please refer to the R2xx User Guide document where the built-in functionality is described in detail.

Overview of Actions	
<b>0000</b>	No operation of the corresponding interrupt/timer/counter
<b>0001</b>	Change to power mode 0. In case this was triggered by a timer, the timer will stop.
<b>0002</b>	Change to power mode 1. In case this was triggered by a timer, the timer will stop.
<b>0003</b>	Change to power mode 2. In case this was triggered by a timer, the timer will stop.
<b>0004</b>	Change to power mode 3. In case this was triggered by a timer, the timer will stop.
<b>0005</b>	Change to power mode 0. In case this was triggered by a timer, the timer will restart.
<b>0006</b>	Change to power mode 1. In case this was triggered by a timer, the timer will restart.
<b>0007</b>	Change to power mode 2. In case this was triggered by a timer, the timer will restart.
<b>0008</b>	Change to power mode 3. In case this was triggered by a timer, the timer will restart.
...	Reserved
<b>0010</b>	If I am a Mobile/Sleepy end device Poll Parent for data and stop timer (if applicable)
<b>0011</b>	If I am a Mobile/Sleepy end device Poll Parent for data and restart timer (if applicable)
<b>0012</b>	If I am a Sink advertise and stop timer (if applicable)
<b>0013</b>	If I am a Sink advertise and restart timer (if applicable)
<b>0014</b>	Check for neighbours in local neighbour table. If no neighbours are present for 5 consecutive times leave the PAN. Note: It takes about 80 seconds for a neighbour to age out of the neighbour table.
<b>0015</b>	In case I am not joined to a network scan for and join the next best network and stop the timer (if applicable)
<b>0016</b>	In case I am not joined to a network scan for and join the next best network and restart the timer (if applicable)
<b>0017</b>	Allow joining for 60 Seconds (in case it is disabled in S06) and stop timer (if applicable)
<b>0018</b>	Copy local inputs to remote outputs: Read the local S11 and if changed since the previous time, write the reading to the remote S0F, whose address is given in S2B. If applicable the timer will stop.
<b>0019</b>	Same as 0018, but if applicable the timer will restart.
<b>001A</b>	Copy remote inputs to local outputs: Read the remote unit's S11, whose address is given in S2C and write the reading to the local S0F. If applicable the timer will stop.
<b>001B</b>	Same as 001A, but if applicable the timer will restart.
...	Reserved
<b>002x</b>	Toggle I/Ox and stop timer (if applicable)
<b>003x</b>	Toggle I/Ox and restart timer (if applicable)
<b>004x</b>	Flash I/Ox (pull low) for 250ms and restart timer afterwards
...	Reserved
<b>0100</b>	Sends the reading of the I/O and the two analogue ports to the network's sink and if no sink is known the unit will search for a sink instead. After 3 unsuccessful transmissions the sink is assumed unavailable and a new sink is searched. If applicable the timer will stop.
<b>0101</b>	Sends the reading of the I/O and the two analogue ports to the network's sink and if no sink is known the unit will search for a sink instead. After 3 unsuccessful transmissions the sink is assumed unavailable and a new sink is searched. If applicable the timer will restart.

Telegesis		TG-ETRX-R212-AT-Commands	59
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### Overview of Actions (continued)

<b>0102</b>	Same as 0100, but to charge an external RC timer I/O7 is pulled high whilst sending the data and left high impedance the rest of the time.
<b>0103</b>	Same as 0101, but to charge an external RC timer I/O7 is pulled high whilst sending the data and left high impedance the rest of the time.
<b>0108</b>	The unit sends the contents of S2B to the networks sink. If applicable the timer will stop.
<b>0109</b>	The unit sends the contents of S2B to the networks sink. If applicable the timer will restart.
<b>010A</b>	The unit sends the contents of S2C to the networks sink. If applicable the timer will stop.
<b>010B</b>	The unit sends the contents of S2C to the networks sink. If applicable the timer will restart.
...	Reserved
<b>0110</b>	Sends the reading of the I/O and the two analogue ports as well as an 8-bit transmission counter which increments with every transmission to the network's sink and if no sink is known the unit will search for a sink instead. After 3 unsuccessful transmissions the sink is assumed unavailable and a new sink is searched. If applicable the timer will stop.
<b>0111</b>	Sends the reading of the I/O and the two analogue ports as well as an 8-bit transmission counter which increments with every transmission to the network's sink and if no sink is known the unit will search for a sink instead. After 3 unsuccessful transmissions the sink is assumed unavailable and a new sink is searched. If applicable the timer will restart.
<b>0112</b>	Same as 0110, but to charge an external RC timer I/O7 is pulled high whilst sending the data and left high impedance the rest of the time.
<b>0113</b>	Same as 0111, but to charge an external RC timer I/O7 is pulled high whilst sending the data and left high impedance the rest of the time.
<b>0120</b>	Sends the contents of S2B as a RAW transmission. If applicable the timer will stop.
<b>0121</b>	Same as 0120, but if applicable the timer will restart.
<b>0122</b>	Sends the contents of S2C as a RAW transmission. If applicable the timer will stop.
<b>0123</b>	Same as 0122, but if applicable the timer will restart.
...	Reserved
<b>0200</b>	Show status on I/O10. LED on (pin driven low) = no connection. Blinking fast = Auto-searching for PAN. Blinking slow = connected to PAN. The accompanying counter register defines the update interval. Note: I/O10 must be defined to be an output in S0D/S0E.
<b>0201</b>	Show AT Command line's error status on I/O11. LED off no error. LED blinking = error. Reset by 'OK' prompt. The accompanying counter register defines the update interval. Note: I/O11 must be defined to be an output in S0D/S0E.
...	Reserved
<b>2000</b>	When triggered the number of times listed in the accompanying counter a message is sent to the sink containing a transmission counter and the reading of the analogue and digital inputs. Note: Can only be triggered by setting S15 or S16 to 400x.
<b>2001</b>	When enabling this action the command line is disabled and as soon as a number of bytes in excess of the number N specified in the accompanying timer/counter register is received on the serial port, a SCAST containing these characters is sent to the network's sink. If no sink is known a sink is searched instead. After 3 unsuccessful transmissions the sink is assume unavailable and a new sink is searched. <b>Notes:</b> This event is triggered by receiving a character on the serial port. $N \leq 64$ .
...	Reserved
<b>3000</b>	The contents of S2B is sent to the local command line <sup>2</sup> followed by carriage return. If applicable the timer will stop. Note: No AT-Prefix required!
<b>3001</b>	The contents of S2B is sent to the local command line <sup>1</sup> followed by carriage return. If applicable the timer will restart. Note: No AT-Prefix required!
<b>3002</b>	The contents of S2C is sent to the local command line <sup>1</sup> followed by carriage return. If applicable the timer will stop. Note: No AT-Prefix required!

<sup>2</sup> All commands being entered at the instance this action is triggered are interrupted and overwritten.

Telegesis		TG-ETRX-R212-AT-Commands	60
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### Overview of Actions (continued)

<b>3003</b>	The contents of S2C is sent to the local command line <sup>1</sup> followed by carriage return. If applicable the timer will restart. Note: No AT-Prefix required!
...	Reserved
<b>400x</b>	Start timer x. If applicable the timer will stop.
<b>401x</b>	Start timer x. If applicable the timer will restart.
<b>402x</b>	Toggle timer x. If applicable the timer will stop.
<b>403x</b>	Toggle timer x. If applicable the timer will restart.
<b>404x</b>	Stop timer x. If applicable the timer will stop.
<b>405x</b>	Stop timer x. If applicable the timer will restart.
...	Reserved
<b>8xxx</b>	Change I/O port to the LSBs and if applicable the timer will stop.
<b>9xxx</b>	Change I/O port to the LSBs and if applicable the timer will restart.
<b>Axxx</b>	Change data direction of the I/O port to the LSBs and if applicable the timer will stop.
<b>Bxxx</b>	Change data direction of the I/O port to the LSBs and if applicable the timer will restart.
...	Reserved

Telegesis		TG-ETRX-R212-AT-Commands	61
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 6 Power Consumption

As the module's power consumption is firmware dependent, the values in the following tables supersede any of the numbers given in previous revisions of the AT command dictionary. Table 7 gives the hardware dependent theoretical figures for the ETRX1 as stated in the current hardware manual, whereas table 8 shows the firmware dependent average power consumption of an ETRX1 measured with light to medium network traffic.

Table 9 and 10 represent those figures for the ETRX2 respectively.

### 6.1 ETRX1 Power Consumption

Typical values at 3.3V 25°C.

Parameter	Min.	Typ.	Max.	Units	Condition
Supply Current		30		mA	TX -1dBm
		22		mA	TX -10dBm
		19		mA	TX -20dBm
		18		mA	TX -30dBm
		29		mA	RX
		20		µA	Asleep, Timers on
		15		µA	Asleep, Timers off

**Table 7: Power Consumption**

Mode	Router, COO				MED, SED			
	MCU	Radio	Timers	I	MCU	Radio	Timers	I
0	Awake	Awake	User defined	29mA	Awake	Asleep	User defined	11mA
1	Idle	Awake	User defined	23mA	Idle	Asleep	User defined	6mA
2	Awake	Awake	User defined	1 mA <sup>3</sup>	Asleep	Asleep	User defined	1 mA <sup>1</sup>
3	Asleep	Asleep	off	15µA	Asleep	Asleep	Off	15µA

**Table 8: Averaged power consumption during operation**

#### Notes:

- Sleep modes 1-3 should not be used on a router or coordinator, however it was found that mode 1 may work on a router with light to medium network traffic. Successful operation of a router in mode 1 cannot be guaranteed and needs to be evaluated carefully for each target application in case the additional energy saving is vital.
- Wakeup from mode 3 is only possible by external interrupt or reset. Make sure never to set the initial power mode (S2A) to mode 03 unless you want the device to always wake up into this mode.
- Modules in power mode 2 and 3 will not respond to commands on the command line, so always make sure you have defined means to wake it up from these modes.
- If no means of waking up from any of the power down modes has been defined and the module appears unresponsive the Telegesis factory default resetter can be used to reset the modules factory defaults via the serial port.

<sup>3</sup> Assuming the unit polls every second. If no polling and other timed actions are performed the power consumption can be as little as 20µA in this mode.

Telegesis		TG-ETRX-R212-AT-Commands	62
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 6.2 ETRX2 Power Consumption

Typical values at 3.3V 25°C.

Parameter	Min.	Typ.	Max.	Units	Condition
Supply Current		36		mA	TX 4dBm
		32		mA	TX -1dBm
		29		mA	TX -10dBm
		28		mA	TX -20dBm
		37		mA	RX
		1.5		µA	Asleep, Timers on
		0.7		µA	Asleep, Timers off

**Table 9: Power Consumption**

Mode	Router, COO				MED, SED			
	MCU	Radio	Timers	I	MCU	Radio	Timers	I
0	Awake	Awake	User defined	36mA	Awake	Asleep	User defined	9mA
1	Idle	Awake	User defined	32mA	Idle	Asleep	User defined	4.5mA
2	Awake	Awake	User defined	0.7mA <sup>4</sup>	Asleep	Asleep	User defined	0.7mA <sup>1</sup>
3	Asleep	Asleep	off	0.7µA	Asleep	Asleep	Off	0.7µA

**Table 10: Averaged power consumption during operation**

### Notes:

- Sleep modes 1-3 should not be used on a router or coordinator, however it was found that mode 1 may work on a router with light to medium network traffic. Successful operation of a router in mode 1 cannot be guaranteed and needs to be evaluated carefully for each target application in case the additional energy saving is vital.
- Wakeup from mode 3 is only possible by external interrupt or reset. Make sure never to set the initial power mode (S2A) to mode 03 unless you want the device to always wake up into this mode.
- Modules in power mode 2 and 3 will not respond to commands on the command line, so always make sure you have defined means to wake it up from these modes.
- If no means of waking up from any of the power down modes has been defined and the module appears unresponsive the Telegesis factory default resetter can be used to reset the modules factory defaults via the serial port.
- In order to achieve ultra low power consumption of sub 1µA it is required to either define all I/Os to be outputs, or to pull all inputs to a defined level as floating input pins will increase the current consumption. Furthermore as described in the hardware manual a pull down of 10kΩ must be attached to the SIF\_MOSI pin for lowest possible power consumption.

For more details please refer to the separate application note regarding power consumption, which can be found on [www.telegesis.com](http://www.telegesis.com).

<sup>4</sup> Assuming the unit polls every second. If no polling and other timed actions are performed the power consumption can be as little as 1.5µA in this mode.

Telegesis		TG-ETRX-R212-AT-Commands	63
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 7 Notes on Backwards Compatibility With ETRX1

EmberZNet2.x (R2xx) is not over-the-air compatible to EmberNet3.3 (R1xx), so OTA bootloading the firmware from a device running EmberZNet2.x to a device running EmberNet3.3 or vice versa is not possible.

In order to over-the-air upgrade devices running R1xx to R2xx you must use the pass-through bootloader (available from R112 onwards) on an R1xx device as described in the Development Kit manual.

When upgrading an ETRX1 module from R1xx to R2xx you must ensure that the Ember bootloader on the target node has version number 1004 or higher. In order to find out the revision number of the local bootloader simply enter the bootloader using the **AT+BLOAD** command. After pressing 'enter', the first line of the bootloader menu will show the revision number of the bootloader which will be either 1001, 1004 or 1005. If the revision number is 1001 please contact Telegesis about upgrading the bootloader.

**Note:** For cloning a local nodes firmware to a remote node, the local nodes bootloader revision must be 1005 or higher.


The new firmware will detect R1xx EEPROM entries and translate them to R2xx ones. Downgrading from R2xx to R1xx currently is not possible as there are no provisions to downgrade the EEPROM entries. If you require to downgrade from R2xx to R1xx please contact [zigbeesupport@telegesis.com](mailto:zigbeesupport@telegesis.com) for instructions.

Telegesis		TG-ETRX-R212-AT-Commands	64
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 8 Notes on Energy Levels and LQI

### 8.1 Interpreting LQI on the ETRX2

On the EM250, which contains the radio for the ETRX2 module, the LQI is closely related to the SNR (signal noise ratio). The graph below shows the relation between the SNR and the LQI reading.



**Figure 1: LQI vs. SNR (source : Ember)**

With EmberZNet2.5 (R208 onwards) the maximum (best) LQI reading has been increased from 0xF0 (EmberZNet2.3 - R207) to 0xFF.

From the LQI the stack calculates the cost for a particular link based on the following table:

Cost	LQI
1	254 - 255
3	247 - 253
5	200 - 246
7	0 - 199

**Table 11: LQI/Cost relationship**

Telegesis		TG-ETRX-R212-AT-Commands	65
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 8.2 Interpreting LQI on the ETRX1

On the EM2420, which is the radio on the ETRX1 module, the LQI is based on the link correlator error output, so effectively on the PER.

The hexadecimal reading of the LQI can be interpreted as follows: Numbers 0 to 80 correspond linearly to 0 to 80%. Then between 80 and 255, it is still linear but from 81 to 255 corresponds to the values 80.x to 100%.

With EmberZNet2.5 (R208 onwards) the maximum (best) LQI reading has been increased from 0xF0 (EmberZNet2.3 - R207) to 0xFF.

From the LQI the stack calculates the cost for a particular link based on the following table:


Cost	LQI
1	248 - 255
3	238 - 247
5	200 - 237
7	0 - 199

**Table 12:** LQI/Cost relationship

Telegesis		TG-ETRX-R212-AT-Commands	66
ETRX1 and ETRX2		AT-Command Dictionary	2.12

### 8.3 Interpreting RSSI Energy Levels on the ETRX1

The readings from **AT+ESCAN** on the ETRX1 represent the hexadecimal readings from the EM2420's RSSI register, offset by +127 to make it a positive number.



**Figure 2: RSSI Register Value (source: EM2420 datasheet)**

The actual RF-level in dBm for each RSSI register value can be obtained from [Figure 2](#).

### 8.4 Interpreting RSSI Energy Levels on the ETRX2

On the ETRX2 the readings from AT+ESCAN represent the hexadecimal readings from the EM250's RSSI register, offset by +127 to make it a positive number.

Since the actual radio hardware differs from the ETRX1 the readings will differ from the ones observed on the ETRX2.

The EM250 calculates the RSSI over an 8-symbol period as well as at the end of a received packet. It utilizes the RX gain settings and the output level of the ADC within its algorithm. The linear range of RSSI is specified to be 40dB over all temperatures. At room temperature, the linear range is approximately 60dB (-90 dBm to -30dBm).

<b>Telegesis</b>		TG-ETRX-R212-AT-Commands	67
ETRX1 and ETRX2		AT-Command Dictionary	2.12

## 9 Trademarks

All trademarks, registered trademarks and products names are the sole property of their respective owners.

## 10 Disclaimer

Product and Company names and logos referenced may either be trademarks or registered trademarks of their respective companies. We reserve the right to make modifications and/or improvements without prior notification. All information is correct at time of issue. Telegesis (UK) Ltd does not convey any license under its patent rights or assume any responsibility for the use of the described product.

## 11 Contact Information

Website: [www.telegesis.com](http://www.telegesis.com)  
E-mail: [sales@telegesis.com](mailto:sales@telegesis.com)

Telegesis (UK) Limited  
Marlow Business Centre  
84 Station Road  
Marlow  
Bucks. SL7 1NX  
UK

Tel: +44 (0)1628 894347  
Fax: +44 (0)1628 894333

## 12 References

Telegesis - [www.telegesis.com](http://www.telegesis.com)

Ember - [www.ember.com](http://www.ember.com)

Atmel - [www.atmel.com](http://www.atmel.com)